



## Millennium Xtra

### Technical Bulletin

**Title:** Configuring Hot Commands in Xtra

#### Contents:

To setup Hot Commands go to **System Configuration > Hot Commands Configuration**

Current Threat Level: **Normal**

System Administration | Cardholder Data | Event Monitoring | Hardware Configuration | **System Configuration** | Reports | Historical Log | Maps

Millennium Xtra | Logged User: admin | Time Online: 00:00 | Base Online: 20:49

Time Periods | Holidays | Access Levels | Groups | Alarm Routing Templates | Alarm Acknowledgment Templates | Alarm/Event Definition | **Hot Commands Configuration**

▼ All Commands  
No items

**Hot Commands Configuration**

Hot Command Name:

Device Type: **Doors** ▼

Device:  ▼

Command: **Lock** ▼

**New** **Copy** **Save** **Delete** **Cancel** **Help**

©2000–2013 Millennium Group, Inc. | [Change Password](#) - [Company Info](#) - [Privacy Policy](#) - [Open in Separate Window](#)

Click  **New** button

Enter **Hot Command Name** :

Hot Command Name:  
Lock Door 1  
Device Type:  
Outputs  
Device:  
  
Command:  
Activate

Select **Device Type** to which command will be sent:

Hot Command Name:  
Lock Door 1  
Device Type:  
Doors  
Outputs  
Inputs  
Doors  
Readers

Select **Device** to which command will be sent:

Hot Command Name:  
Lock Door 1  
Device Type:  
Doors  
Device:  
Door1  
Door1  
Door2

Select **Command** to execute:

Hot Command Name:  
Lock Door 1  
Device Type:  
Doors  
Device:  
Door1  
Command:  
Lock  
Lock  
Unlock  
Normal  
Momentary Unlock

Save changes by clicking  button

This Hot Command will now be available in the Hot Commands quick panel

Click **Hot Command** shortcut



Send command by clicking **Send** button

